

# trim spot

## installation instruction

1

HOUSING

IC AT

or

HOUSING

IC AT

or

REMODEL

IJB

Install the appropriate IC/driver box.

2

Install the drywall (thickness 1/2") with a round hole (Ø 2-2/3").

3

See packaging or fixture label for maximum current.

4

Connect the wires with wago connectors.  
For serial connection, respect polarity.  
Combine with a prado LED-driver.


5

Bend over the springs and push the luminaire into the ceiling.

6

POWER ON

Turn the power back on.  
Thank you for choosing prado.



Replace glass lens when broken.

Luminaire shall only be used together with glass lens.

prado.com

The light source in this luminaire shall only be replaced by the manufacturer or a similar qualified person. Warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair the product.