
prado


acrotrack 48V
installation instruction

1



slide the luminaire in the prado 48V track
make sure to use a prado 48V LED-driver
Dali driver is non polarised and 0-10V driver is polarised

2



twist the luminaire as desired
thank you for choosing prado

IP 44

Replace glass lens when broken.
Luminaire shall only be used together with glass lens.

prado.com

The light source in this luminaire shall only be replaced by the manufacturer or a similar qualified person. Warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair the product.